

Installation

- Remove existing timber edge trims and put them to one side if they can be reused
- Remove old roof covering, any fixings and replace any rotten deck boards
- Ensure that the deck surface is clean and dry .
- Place the EPDM Rubber onto shed roof, ensuring equal coverage
- Wait 30 mins for EPDM to relax
- Fold back half of the EPDM Membrane to expose the timber deck and apply the adhesive evenly with a roller
- Roll the membrane back into the adhesive, use a soft broom to ensure no air is trapped beneath the membrane
- Repeat the process for the other half of the roof
- Using scissors, cut off any excess Rubber, leaving approx . 50 mm overhang
- Fix trims to the perimeter edges



 [01392 927729](tel:01392927729)

 www.rubberflatroof.co.uk

 sales.rubberflatroof.co.uk



What you will need?

- EPDM Rubber (included)
- Adhesive (included)
- Roller (included)
- Soft Broom
- Scissors
- Trims & Hammer (optional)

